



Over-Rider Conversion for Fitment with Sports Valance



Wolf Performance Ltd
Walnut Forge, Wimpole Road
Barton
Cambridge
CB23 7AD

07944 720706

cain@wolfperformance.co.uk

www.wolfperformance.co.uk



This conversion is for changing the “angle-iron” type Over-riders to a “tube” type that is suitable for mounting with a Sports Valance.

1. Cut the Over-rider mounts so that it sits behind the valance line
2. Make up tube extension and mounting plate for the over-riders (will require welding)
3. Fit valance and drill holes to allow the tubes to pass through
4. Insert the over-rider tube mounts through the holes and drill through both the angle-iron mount and the tube
5. Secure the tubes to the angle-iron