



Rebound Spring Gaiters Installation Notes



Wolf Performance Ltd
Walnut Forge, Wimpole Road
Barton
Cambridge
CB23 7AD

00 44 (0) 1223 789 658

cain@wolfperformance.co.uk

www.wolfperformance.co.uk

Bearing Location



The bearings located into the recess inside the gaiter. There is a slight bulge at this point.



Trim the gaiters to size

You will have to trim the skirt below the bellows, so that the gaiter sits straight.

If you are having trouble installing the gaiters you can trim the cross-head to give you more space.



Modifications to End of Cross-axle